This Page Is Inserted by IFW Operations
and is not a part of the Official Record

BEST AVAILABLE IMAGES

Defective images within this document are accurate representations of the original documents submitted by the applicant.

Defects in the images may include (but are not limited to):

- BLACK BORDERS
- TEXT CUT OFF AT TOP, BOTTOM OR SIDES
- FADED TEXT
- ILLEGIBLE TEXT
- SKEWED/SLANTED IMAGES
- COLORED PHOTOS
- BLACK OR VERY BLACK AND WHITE DARK PHOTOS
- GRAY SCALE DOCUMENTS

IMAGES ARE BEST AVAILABLE COPY.

As rescanning documents *will not* correct images, please do not report the images to the Image Problem Mailbox.


111
TOP GATE DRIVER
ϕtg
120
114
115
113
200
100
PRE-CHARGE SWITCH
ϕpg
PHOTOSENSOR ARRAY
COLUMN SWITCH
CONTROLLER
EXTERNAL FUNCTION SECTION
116
117
AMPLIFIER
A/D CONVERTER
BOTTOM GATE DRIVER
ϕbg
RAM
130
112

FIG.1


120
111
TOP GATE DRIVER
112
BOTTOM GATE DRIVER
113
OUTPUT CIRCUIT SECTION
φtg
φbg
φpg
121
DEVICE CONTROLLER
123
MAIN CONTROLLER
200
EXTERNAL FUNCTION SECTION
127
SENSITIVITY SETTING REGISTER
122
DATA CONTROLLER
117
A/D CONVERTER
124
DATA COMPARATOR
125
ADDER
DATA SELECTOR
126
130
RAM

FIG.2


START
SENSITIVITY-ADJUSTING READING OPERATION
S11
CONVERT IMAGE DATA
S12
EXTRACT MAXIMUM AND MINIMUM VALUES OF EACH ROW
S13
CALCULATE DYNAMIC RANGE OF EACH ROW
S14
EXTRACT ROW NUMBER HAVING MAXIMUM DYNAMIC RANGE
S15
REFER TO AND EXTRACT SENSITIVITY
S16
SET EXTRACTED SENSITIVITY
S17
READ SUBJECT IMAGE
S18
END

FIG.3



FIG.4



FIG.5A



FIG.5B



FIG.5C



FIG.5D



FIG.5E

FIG.6A

ROW NUMBER	80TH ROW	104TH ROW	128TH ROW	152ND ROW	176TH ROW
MAXIMUM VALUE	25	127	251	255	255
MINIMUM VALUE	0	0	27	153	249
DYNAMIC RANGE	25	127	224	102	6

FIG.6B

ROW NUMBER	1ST ROW	. . .	128TH ROW	. . .	256TH ROW
CHARGE ACCUMLATING PERIOD	T1	. . .	T128	. . .	T256



FIG.7



FIG.8A



FIG.8B



FIG.8C



FIG.8D



FIG.8E

FIG.9A

ROW NUMBER	80TH ROW	104TH ROW	128TH ROW	152ND ROW	176TH ROW
MAXIMUM VALUE	23	117	243	255	255
MINIMUM VALUE	0	9	27	193	255
DYNAMIC RANGE	23	108	216	62	0

FIG.9B

ROW NUMBER	1ST ROW	. . .	128TH ROW	. . .	256TH ROW
CHARGE ACCUMLATING PERIOD	T_1	. . .	T_{128}	. . .	T_{256}


START
SENSITIVITY-ADJUSTING READING OPERATION
S21
CONVERT IMAGE DATA
S22
EXTRACT DATA IN COLUMN DIRECTION
S23
DIFFERENTIAL PROCESSING IN COLUMN DIRECTION
S24
EXTRACT ROW NUMBER HAVING MAXIMUM DIFFERENTIATED VALUE
S25
REFER TO AND EXTRACT SENSITIVITY
S26
SET EXTRACTED SENSITIVITY
S27
READ SUBJECT IMAGE
S28
END

FIG.10



FIG.11



FIG.12A



FIG.12B

FIG.13A

ROW NUMBER	. . .	121ST ROW	122ND ROW	123RD ROW	124TH ROW	125TH ROW	126TH ROW	127TH ROW	128TH ROW	129TH ROW	. . .
DIFFERENTIATED VALUE	. . .	80	53	72	5	95	11	76	20	. . .	

FIG.13B

ROW NUMBER	. . .	121ST ROW	122ND ROW	123RD ROW	124TH ROW	125TH ROW	126TH ROW	127TH ROW	128TH ROW	129TH ROW	. . .
CHARGE ACCUMLATING PERIOD	. . .	T_{121}	T_{122}	T_{123}	T_{124}	T_{125}	T_{126}	T_{127}	T_{128}	T_{129}	. . .


START
SENSITIVITY-ADJUSTING READING OPERATION
S31
CONVERT IMAGE DATA
S32
EXTRACT DATA IN COLUMN DIRECTION
S33
CALCULATED DYNAMIC RANGE OF EACH ROW
S34
CALCULATE LINEARLY DIFFERENTIATED VALUE OF THE DYNAMIC RANGE
S35
EXTRACT ROW NUMBER HAVING MAXIMUM DYNAMIC RANGE AND MINIMUM LINEARLY DIFFERENTIATED VALUE
S36
REFER TO AND EXTRACT SENSITIVITY
S37
SET EXTRACTED SENSITIVITY
S38
READ SUBJECT IMAGE
S39
END

FIG.14



FIG.15


191ST ROW
160TH ROW
96TH ROW
64TH ROW
LIGHTNESS DATA VALUE
255
200
150
100
50
0
67
81
95
109
130
COLUMN NUMBER

FIG.16



FIG.17A



FIG.17B

FIG.18A

ROW NUMBER	64TH ROW	. . .	Lk-1 ROW	Lk ROW	Lk+1 ROW	. . .	191ST ROW
MAXIMUM VALUE	X64	. . .	XK-1	XK	XK+1	. . .	X191
MINIMUM VALUE	Y64	. . .	YK-1	YK	YK+1	. . .	Y191
DYNAMIC RANGE	R64	. . .	RK-1	RK(MAX)	RK+1	. . .	R191
LINEARLY DIFFERENTIATED VALUE	. . .		Dk-2	Dk-1(MIN)	Dk	Dk+1	. . .

FIG.18B

ROW NUMBER	64TH ROW	. . .	Lk-1 ROW	Lk ROW	Lk+1 ROW	. . .	191ST ROW
CHARGE ACCUMLATING PERIOD	T64	. . .	Tk-1	Tk	Tk+1	. . .	T191

FIG.19A

ROW NUMBER	64TH ROW	. . .	Lk-1 ROW	Lk ROW	Lk+1 ROW	. . .	191ST ROW
MAXIMUM VALUE	X_{64}	. . .	X_{K-1}	X_K	X_{K+1}	. . .	X_{191}
MINIMUM VALUE	Y_{64}	. . .	Y_{K-1}	Y_K	Y_{K+1}	. . .	Y_{191}
DYNAMIC RANGE	R_{64}	. . .	R_{K-1}	$R_{K(MAX)}$	R_{K+1}	. . .	R_{191}

FIG.19B

ROW NUMBER	64TH ROW	. . .	Lk-1 ROW	Lk ROW	Lk+1 ROW	. . .	191ST ROW
CHARGE ACCUMLATING PERIOD	T_{64}	. . .	T_{k-1}	T_k	T_{k+1}	. . .	T_{191}



FIG.20



FIG.21



FIG.22A



FIG.22B


START
SENSITIVITY-ADJUSTING READING OPERATION
S41
CONVERT IMAGE DATA
S42
EXTRACT MAXIMUM AND MINIMUM VALUES OF EACH ROW
S43
CALCULATE DYNAMIC RANGE OF EACH ROW
S44
CALCULATE LINEARLY DIFFERENTIATED VALUE OF THE DYNAMIC RANGE
S45
EXTRACT ROW NUMBER HAVING MAXIMUM DYNAMIC RANGE AND MAXIMUM LINEARLY DIFFERENTIATED VALUE
S46
S47
DETERMINE PRESENCE/ABSENCE OF AN EXTRACTED ROW
PRESENCE OF EXTRACTED ROW
PRESENCE OF ABNORMAL PIXEL
ABSENCE OF EXTRACTED ROW
ABSENCE OF ABNORMAL PIXEL

FIG.23


120a
111
TOP GATE DRIVER
112
BOTTOM GATE DRIVER
113
OUTPUT CIRCUIT SECTION
φtg
φbg
φpg
DEVICE CONTROLLER
121
123
MAIN CONTROLLER
200
EXTERNAL FUNCTION SECTION
127
SENSITIVITY SETTING REGISTER
122
DATA CONTROLLER
117
A/D CONVERTER
128a
FOURIER TRANSFORMATION CIRCUIT
128b
FILTERING CIRCUIT
128c
INVERSE FOURIER TRANSFORMATION CIRCUIT
128
124
DATA COMPARATOR
125
ADDER
DATA SELECTOR
126
130
RAM

FIG.24


START
SENSITIVITY-ADJUSTING READING OPERATION
S51
CONVERT IMAGE DATA
S52
FOURIER TRANSFORMATION
S53
REMOVE HIGH-FREQUENCY COMPONENT
S54
INVERSE FOURIER TRANSFORMATION
S55
EXTRACT MAXIMUM AND MINIMUM VALUES OF EACH ROW
S56
CALCULATED DYNAMIC RANGE OF EACH ROW
S57
CALCULATE LINEARLY DIFFERENTIATED VALUE OF DYNAMIC RANGE
S58
EXTRACT ROW NUMBER HAVING MAXIMUM DYNAMIC RANGE AND MINIMUM LINEARLY DIFFERENTIATED VALUE
S59
REFER TO AND EXTRACT SENSITIVITY
S60
SET EXTRACTED SENSITIVITY
S61
READ SUBJECT IMAGE
S62
END

FIG.25



FIG.26



FIG.27A



FIG.27B


START
SENSITIVITY-ADJUSTING READING OPERATION
S71
IMAGE DATA CONVERSION
S72
EXTRACTING MAXIMUM VALUE AND MINIMUM VALUE IN EACH READING OPERATION
S73
CALCULATING A DYNAMIC RANGE IN EACH READING OPERATION
S74
EXTRACTING READING OPERATION THAT EXHIBITS MAXIMUM DYNAMIC RANGE
S75
REFERRING TO AND EXTRACTING SENSITIVITY
S76
SETTING EXTRACTED SENSITIVITY
S77
END

FIG.28



FIG.29



FIG.30A



FIG.30B



FIG.30C



FIG.30D



FIG.30E


DLmax
DYNAMIC RANGE
RCa
NUMBER OF TIMES OF
READING OPERATION

FIG.31


START
SENSITIVITY-ADJUSTING READING OPERATION
S81
IMAGE DATA CONVERSION
S82
EXTRACTING AND COMPARING SAME-COLUMN DATA FROM DATA OF EACH READING OPERATION
S83
S84
DETERMINING VARIATION IN SAME-COLUMN DATA
COLUMN IN WHICH DATA REMAIN THE SAME PRESENTS
S85
CHANGING ROW SECTION FOR WHICH SENSITIVITY-ADJUSTING READING OPERATION
NO COLUMN IN WHICH DATA REMAIN THE SAME PRESENTS
EXTRACTING MAXIMUM VALUE AND MINIMUM VALUE IN EACH READING OPERATION
S86
CALCULATING DYNAMIC RANGE IN EACH READING OPERATION
S87
EXTRACTING READING OPERATION THAT EXHIBITS MAXIMUM DYNAMIC RANGE
S88
REFERRING TO AND EXTRACTING SENSITIVITY
S89
SETTING EXTRACTED SENSITIVITY
S90
END

FIG.32



FIG.33



FIG.34A



FIG.34B



FIG.34C



FIG.34D



FIG.34E



FIG.35A

FIG.35E

FIG.35B

FIG.35F

FIG.35C

FIG.35G

FIG.35D

FIG.35H

FIG.35I

FIG.35J

FIG.36A
FIG.36E
FIG.36B
FIG.36F
FIG.36C
FIG.36G
FIG.36D
FIG.36H
FIG.36I
FIG.36J



FIG.37A
FIG.37F

FIG.37B
FIG.37G
FIG.37C
FIG.37H
FIG.37D
FIG.37I
FIG.37E
FIG.37J
FIG.37K
FIG.37L




SENSITIVITY-ADJUSTING READING PERIOD
IMAGE READING PERIOD
EFFECTIVE VOLTAGE ADJUSTING PERIOD
TRESET
TA1
TREAD
TRESET
Ta
TREAD
TTPH
TTPL
TBPLA
TBPH
TBPLB
TDELAY
TA2
TREAD
TAn
TPRCH
TPRCH
VtgH
Vte
VtgL
VbgH
Vbe
VbgL
Vprch
GND
FIG.38A φT1
FIG.38D φB1
FIG.38B φT2
FIG.38E φB2
FIG.38C φTn
FIG.38F φBn
FIG.38G φpg
FIG.38H VD

PRIOR ART

FIG.39A



FIG.39B



PRIOR ART



FIG.40

PRIOR ART

FIG.41A

FIG.41B

FIG.41C

FIG.41D